Presenting

DAD 141.1 – Connection to the LAN

Factory default TCP/IP address is: 192.168.0.100

- The LAN address range must be for AAA.BBB.CCC.xxx in the same range for PC and DAD 141.1

1. You can adjust the LAN address to DAD 141.1 default
2. Or adjust the DAD 141.1 address to LAN

1. Adjust LAN of PC network

- ✓ … in only 15 seconds
- ✓ Stop / Finish WIFI - if enabled
- ✓ Connect the LAN cable to DAD 141.1 and PC / Notebook
- ✓ Right mouse click on LAN icon (task bar right)
- ✓ Double click on Ethernet (for LAN setup)
- ✓ … the next steps show how to adjust the address

Adjust LAN Address - Step 1



LAN Connection Status - Step 2



… click on Details…

Network Connection Details - Step 3



… see the IPv4 Address

and Close again

LAN Connection Properties - Step 4



… scroll down to TCP/IPv4

Connection Properties: choose TCP/IPv4 - Step 5



… double click on TCP/IPv4

Status IP Version 4 - Step 6



… IP address automatically

must be change to …

Setup IP Address - Step 7



… use the following IP address

Setup
- IP address,
- subnet mask,
- gateway

… and confirm with OK

DOP 4 – Test Device For LAN



DOP 4 – Select Device For LAN



DOP 4 – Set Device To Channel 2



DOP 4 – Start Test Stream Channel 1 & 2



DOP 4 – Ready For Measurements



2. Or Adjust the DAD 141.1 Address to the LAN

In DAD 141.1 Menu 8: Data Communication

- Sub-Menu 8.6: IP Address of Ethernet port

  - In decimal notation per 3 characters

  - Factory default: 192.168.0.100

8.6.x	Example for factory default - AAA.BBB.CCC.DDD	
8.6.1	AAA	000192
8.6.2	BBB	000168
8.6.3	CCC	000000
8.6.4	DDD	000100